HOSPAN

Foot Spa Manual

Model: FS-2024 Professional Series

Downloaded from: https://hospan.org/

Table of Contents

- Important Safety Information
- Product Overview
- Technical Specifications
- · What's in the Box
- Assembly Instructions
- Operating Instructions
- Care and Maintenance
- Troubleshooting
- Warranty Information
- Contact Information

△ Important Safety Information

READ ALL INSTRUCTIONS BEFORE USE

- Always unplug the unit when not in use
- Do not use with damaged power cord or plug
- · Keep electrical components away from water
- Do not exceed maximum water level
- Not recommended for children under 12 years
- Consult physician before use if you have diabetes, circulation problems, or foot injuries
- Do not use if pregnant without medical consultation
- Water temperature should not exceed 104°F (40°C)
- Maximum usage time: 30 minutes per session
- Never leave unit unattended while in use

Product Overview

The HOSPAN Foot Spa FS-2024 is a professional-grade foot spa designed for home use. It features advanced bubble massage technology, temperature control, and ergonomic design for ultimate comfort and relaxation.

Key Features:

- Digital LED display with temperature readout
- Adjustable temperature control (95°F 104°F)

- Powerful bubble massage system
- Built-in timer (5-30 minutes)
- Removable pumice stone for callus removal
- Splash guard to prevent water spillage
- Non-slip base for stability
- Easy-drain plug for convenient emptying

Technical Specifications

Specification	Details
Model	FS-2024 Professional Series
Power Input	120V AC, 60Hz
Power Consumption	450W
Water Capacity	Maximum 3.5 liters
Temperature Range	95°F - 104°F (35°C - 40°C)
Timer Settings	5, 10, 15, 20, 25, 30 minutes
Dimensions	16" L x 12" W x 8" H
Weight	8.5 lbs (3.9 kg)
Cord Length	6 feet (1.8 meters)

What's in the Box

- HOSPAN Foot Spa Unit (1)
- Removable Pumice Stone (1)
- Splash Guard (1)
- Power Cord (1)
- User Manual (1)
- Warranty Card (1)

Assembly Instructions

Step 1: Unboxing

Carefully remove all components from the packaging. Check that all items listed in "What's in the Box" are present.

Step 2: Initial Setup

- 1. Place the foot spa on a flat, stable surface near an electrical outlet
- 2. Ensure the drain plug is securely closed
- 3. Attach the splash guard to the rim of the unit
- 4. Insert the pumice stone into the designated holder
- 5. Connect the power cord to the unit

Step 3: First Use Preparation

- 1. Clean the foot spa basin with mild soap and water
- 2. Rinse thoroughly and dry completely
- 3. Plug the unit into a grounded electrical outlet

Operating Instructions

Pre-Use Preparation

- 1. Ensure feet are clean before use
- 2. Check water temperature with a thermometer if needed
- 3. Remove any jewelry from feet and ankles
- 4. Have a towel ready for drying feet after use

Operating Steps

- 1. Fill with Water: Add warm water to the basin. Do not exceed the MAX water level line. Recommended water level is between MIN and MAX markers.
- 2. Power On: Press the power button. The LED display will illuminate.
- 3. Set Temperature: Use the temperature control buttons to set desired temperature (95°F 104°F). The display will show current water temperature.
- 4. Set Timer: Press the timer button to select desired duration (5-30 minutes). The display will show remaining time.
- 5. Activate Massage: Press the bubble massage button to start the bubble action.
- 6. Begin Session: Gently place both feet in the water. Adjust position for comfort.

- 7. **During Use:** The unit will maintain the set temperature and provide continuous bubble massage. Use the pumice stone gently on callused areas if desired.
- 8. **End Session:** The unit will automatically shut off when the timer reaches zero. You can also manually turn off the unit at any time.

Control Panel Functions

- Power Button: Turns unit on/off
- Temperature +/-: Adjusts water temperature
- Timer Button: Cycles through time settings
- Bubble Button: Activates/deactivates bubble massage
- LED Display: Shows temperature and remaining time

After Each Use

- 1. Unplug the unit from electrical outlet
- 2. Remove the drain plug to empty water completely
- 3. Wipe the interior with a clean, damp cloth
- 4. Clean the pumice stone with warm soapy water
- 5. Dry all components thoroughly
- 6. Store in a clean, dry location

Weekly Deep Cleaning

- 1. Fill the basin with warm water and add 2 tablespoons of white vinegar
- 2. Let the solution sit for 15 minutes
- 3. Scrub gently with a soft brush to remove mineral deposits
- 4. Rinse thoroughly with clean water
- 5. Dry completely before storage

Monthly Maintenance

- Inspect power cord for damage
- Check drain plug for proper sealing
- Clean air vents with a soft brush
- · Inspect pumice stone for wear and replace if necessary

Storage

- Store in a cool, dry place
- Do not store with water in the basin
- · Wrap cord loosely to prevent damage
- · Keep away from direct sunlight

Troubleshooting

Unit Does Not Turn On

- · Check that power cord is securely plugged in
- Verify electrical outlet is working
- Check for damaged power cord
- Ensure unit is completely dry before use

Water Not Heating

- · Allow 5-10 minutes for water to reach set temperature
- · Check that water level is between MIN and MAX lines
- Verify temperature setting is above current water temperature
- · Contact customer service if heating element appears faulty

No Bubble Action

- Ensure bubble button is pressed and activated
- Check that air vents are not blocked
- · Verify water level is adequate
- Clean air intake filters if clogged

Water Leaking

- · Check that drain plug is securely closed
- Inspect drain plug gasket for damage
- Ensure water level does not exceed MAX line
- Check for cracks in basin

Unusual Noises

- · Verify unit is on stable, level surface
- · Check that nothing is obstructing the motor
- Ensure water level is adequate
- · Contact customer service if noise persists

Warranty Information

HOSPAN Limited Warranty

HOSPAN warrants this product to be free from defects in materials and workmanship for a period of two (2) years from the date of original purchase.

What is Covered:

- Defects in materials and workmanship
- Electrical component failures
- Heating element malfunction
- Motor and pump failures

What is Not Covered:

- Damage from misuse or abuse
- Normal wear and tear
- Damage from accidents or alterations
- · Damage from commercial use
- · Consumable parts (pumice stone, filters)

Warranty Service:

To obtain warranty service, contact HOSPAN customer service with your proof of purchase. Do not return the product to the retailer.

Contact Information

HOSPAN Customer Service

Website: <u>https://hospan.org/</u> Email: support@hospan.org Phone: 1-800-HOSPAN-1 (1-800-467-7261) Hours: Monday-Friday, 9 AM - 6 PM EST

Mailing Address:

HOSPAN Customer Service 1234 Wellness Way Health City, HC 12345 USA

Environmental Responsibility

When disposing of this product, please follow local environmental regulations. Do not dispose of electrical components in regular household waste. Contact your local waste management facility for proper disposal instructions.

HOSPAN Foot Spa Manual - Model FS-2024 Document Version 1.0 | Downloaded from: <u>https://hospan.org/</u> © 2024 HOSPAN. All rights reserved.